



Detail ( A )

Rotate Tool Or Terminal 180 Degrees For Center Crimp

Crimp Per Instructions

1. Slip Front Threaded Plug on to Cable.
2. Slip Cable into 1/8" Sleeve so that it is approximately even with the back of the Sleeve.
3. Slip both the 1/8" Sleeve & the Cable into the 3/16" Sleeve until it is approximately even with the back of the 3/16" Sleeve.
4. Crimp the Sleeve Assembly per instructions (see Detail -A).
5. Install assembly into the Turnbuckle Body and connect with the front Threaded Plug until Tight. (Note Thread Rotation).

Thread Rotation (CCW)

This is the Property of Feeney, Inc. Any reproduction of this document without the expressed consent of Feeney, Inc. is strictly forbidden.

